

Displayed message: "Clean-Me" Faulty module: discriminator Effect: coin acceptance decreased to below an acceptable level Possible cause: dirty coin paths or high slug rejection Action to take:

1. Clean the coin paths—see Cleaning page 34

On the keypad, press **Mode A4 Mode** to clear the fault report and return the LED to green

2. Check the cashbox and coin tubes for slugs
3. Check coin acceptance threshold

Acceptor To clean the acceptor:

- 1 Switch off the power supply to the vending machine
- 2 Open the acceptor by pulling on the left-hand side and lifting upwards and to the right
- 3 Clean the shaded areas shown below, leaving the surfaces clean and dry
- 4 Close the acceptor. Make sure the lid is fully closed
- 5 Switch on the power